

How to upgrade SunTracer

Manuals

1. **PC side:** you must have following files: "suntracer.ehx" and "update.exe". Save them on c:\your_folder.
2. **SunTracer side:** Connect your SunTracer on your PC (on COM port) with serial cable, which was included by SunTracer.
3. **PC side:** open command prompt (START -> RUN -> type: "CMD" -> ENTER) and go to your folder (type "cd c:\your_folder" + enter).
4. **SunTracer side:** disconnect all power supplies from your SunTracer. Push and hold "W" button (button by LED) and connect some power to SunTracer. Orange LED must light forever.
5. **PC side:** type: "update suntracer.ehx -comX", where X means number of COM port your are using. Press ENTER. Transfer will begin.
6. After 100% orange LED will turn off. Upgrade is finished.

Note 1: suntracer.ehx can be: suntracer_og.ehx, suntracer_cbl.ehx, suntracer_wp.ehx or else.

Note 2: if you do not have COM port on your PC, you can use USB-COM adapter.